

Supplemental Dual Battery Conversion Kit Instructions

(Diamond Plate Propane Tub ONLY)

If you are installing the EPS dual battery conversion kit in a T@B with the diamond plate propane tub you will be required to make minor modifications to the tub before installing.

There is a 4" high aluminum lip along the lower rear section of the tub. You will need to trim a notch out of the lower rear cross section 3 ½" from the top and the width of the battery tray. This will allow the battery tray to lay flat and bolt to the bottom of the tub. The aluminum can be cut with a saws-all or jig saw with a metal blade. Be sure to file off any residual metal shavings. It is easiest to completely remove the diamond plate tub to perform this modification. Next follow the instructions included in the Battery Conversion Kit. See Pictures below of the necessary modification before beginning to install your dual battery tray.

